

Side Hinged Doors Fitting Instructions

Contemporary Gear

A proficient DIY installer should be able to install this product, we recommend however that the services of a specialist be engaged.

Please read these instructions right through before attempting installation

Doors are to be fitted in a suitable timber frame , minimum recommended size 70mm x 70mm.

1. Ensure frame is fitted perfectly square, upright and level
2. Check internal frame size and actual panel sizes prior to commencing fitting. The panels should fit in the opening with 3mm clearance all round
3. Mark Hinge positions on door leaves, hinge knuckles must be at front of frame for Woodrite standard outward opening doors.

Hinge Positions

Fit bottom hinges 150mm from bottom of panels

Fit top hinges 100mm from top of panels

Fit remaining hinges equispaced between top/bottom pairs

4. Rebate panels to accept hinges if required and fit using screws provided
5. Mark hinge positions on frame and rebate to accept hinges as required. Fit using screws provided
6. Fit Lock / Handles in pre-machined holes as required.
7. Fit Door Stays using No.10 x 1.1/2" screws provided, refer to instructions in stays box for detailed fitting instructions.
8. Check operation and fine adjust hinges / locking as required.
9. Fit stop beads to timber frame at back of panels when door is in closed position.
10. Fine adjust locking / stays if required
11. Fit Monkey Bolt at top of fixed leaf using No.10 x 1.1/2" screws provided, fit top edge of bolt flush with top of door.
12. Fit Foot Bolt at bottom of fixed leaf using No.10 x 1.1/2" screws provided, fit top edge of bolt flush with bottom of door. Fit latch plate to floor as required using No.8 x 1" Screws provided.

Issue 1 – 1st August 2016