

Door Stays

Part Number ST21235

Fitting Instructions

- 1, open door to form a right angle with the frame and wedge into position . Note if the door is required to open further than 90 degrees then both the brackets must be moved closer to the hinges.
- 2, Fix bracket A to the rear of the frame lintel using 4 x Tek fixing , these are self-drilling and self-tapping and are driven in using a cordless drill , remember to set the torque to avoid over tightening and breaking the thread. Set the level correctly as shown in the picture below. Start with two screws to hold in place to start
- 3, Fix bracket B to the underside of the top bar on the door as shown , only fix with one screw and check operation , if happy then fix remaining screws in place .

