

Notes for 360mm Headplates

Wiring placement for 360mm headplates must follow a similar line as pictured below, the wiring must not go above and care should be taken to ensure the wiring will not get caught in the sliding mechanism.

The plastic protection pieces (pictured white below at the front of the headplate, normally supplied in black) must be placed on installation to protect the curtain.

All fixings must fit within the countersunk part and not protrude in any way, failure to do so will damage the curtain.

