





PATENT PENDING



Full-scale

With the HS 5 BS hand transmitter, you can check whether your door is closed at the press of a button.

A Multicolour LED


Shows the position of the door and radio transmission.

B Inquiry button

To query the door position, simply press the inquiry button and then press the function button. The LED shows if the door is open or closed.

C 4 function buttons

To operate 4 door functions, e.g. Open / Close. Hörmann garage door and entrance gate operators with a radio frequency of 868 MHz (year of manufacture 2005 – 2011) can still be operated.*



Inquiry of the door position

1 To check whether the door is closed, press the inquiry button on the HS 5 BS and then press the function button to open the door. The LED is illuminated in orange.

Door position reporting

2 The LED will flash in red if the door is still open. A closed door is indicated by a green LED.

Convenient closing with automatic door position reporting

3 You can close your door by pressing the function button once more.

Note: An additional photocell is required if the door is not within view.

4 The green LED then indicates that your door is closed.

* Querying the door position is not possible here.