



ALARM OPTION INSTALLATION INSTRUCTIONS




1. Attach the alarm module to the receiver unit.




2. Red wire - terminal 10 Black wire - terminal 16

The alarm should not be activated until the remote control has been commissioned - see sections 9 & 10 of the garage door installation instructions.



1. Press and hold the stop button.
2. Whilst holding down the stop button press the close button.
3. Release both buttons at the same time.

Activating the alarm option



1. Press and release the open button on the hand transmitter. The alarm can not be switched off by the receiver unit. The alarm is triggered when the bottom slat transmitter goes up past the bottom magnet without receiving an instruction from the receiver unit.

Turning off the alarm