

## Quick Start:- Sommer Telecody keypad to CarTeck drive 600 opener

I struggled setting the keypad up, ending up at one stage with the doors opening without any access code, due to wrong sequencing.

This may offer a quick simple step start guide, and is not meant to replace the CarTech or Sommer volumes on 'how to'

## Outside keypad programming to door carriage receiver

It is important to know the access code you want to use before you start!

And to NOTE: the first number must be different for each door, if more than one door is to be programmed!

The examples I use: Door one; I use 3579 and Door two 2468 (any combination of numbers up to nine can be used, so long as the first numbers are different).

- 1 Have easy access to drive motor carriage (steps!) as you will need two hands, pressing buttons and holding the key pad!
- 2 Have the keypad ready, [not screwed to the wall] (if just opened 'new' press 'M' on key pad until it lights up, don't worry if lights go out, unit will still be activated!)
- 3 Remove cover of drive motor carriage and know where the 'radio' button is on the carriage, it's the red one marked 'radio'
- 4 Now we start on the first door (on the steps with the keypad in hand). On the carriage Press the 'radio' button and a red LED will come on
- 5 Keypad      Press      'P'      starts the program sequence  
                  Press      '3'      first number of the chosen access code  
                  Press      'P'      this choses the position of the code  
                  Press      '3'      first number of the chosen access code  
                  Press      '5'      second number of the chosen access code  
                  Press      '7'      third number of the chosen access code  
                  Press      '9'      forth number of the chosen access code  
                  Press      'P'      Programmed but not complete
- 6 Keypad      Press      '3'  
                  Press      '5'  
                  Press      '7'  
                  Press      '9'

Red LED will flash and go out unit is programmed

Keypad: Key in the access code again and the door will operate.

Door two is a repeat of door one with the new access code, ensuring of course that the first number different (it is only the first number that has to be different)

Repeat steps 1 to 4 above

Step 5            P – 2 – P – 2 – 4 – 6 – 8 – P

Step 6            2 – 4 – 6 - 8

Key the access code and door two will operate.

I assume any number of doors could be controlled at least up to nine