

IMPORTANT

For The Safe Operation & Maintenance
of This Door, You Must Follow
These Instructions

HÖRMANN
Garage and Industrial Doors

Hörmann Up & Over Door Series 2000

Basic Operating and Maintenance Instructions For Retractable and Canopy Doors

Note

In using this door it is understood you have read and accepted these operating and maintenance instructions.

Operation

- For opening the door in manual operation use only the outside handle or Internal Rotary Disc. Never use the supplied pull rope during the opening cycle of the door.

- For closing the door from the outside - the pull rope fixed to the Internal Rotary Disc is only designed to pull the door towards you whilst standing within the entrance of the garage until the door can be pushed down by hand, then using the external handle for final closing.
- For closing the door from the inside - the pull rope already mentioned is designed to be pulled away from you, when facing the front entrance of the garage, until the Internal Rotary Disc is able to be reached, by hand, and used for final closing. The pull rope is not designed to be used for any other part of the operating cycle, or any other purpose.
- Failure to comply with the above

instructions may result in injury to persons or property.

- When the door is operated from either outside or inside, check the area through which the door will travel is clear from people and objects. Failure to do so may result in injury to persons or property. When closing, ensure the latches engage properly.
- If the door is power-operated always try to ensure you match the door with a Hörmann operator to ensure full compliance with the Machinery Directive. If another make must be used always consider any compatibility / compliance issues.

Locking

- If the key is turned completely, the door is then locked or unlocked; when unlocked it is then possible to open and close the door by turning the handle.
- If the key is turned 1/4 of the way, the door opened and then the key returned to its start position, the door will re-lock when closed.
- By moving the internal locking "snib", it is possible to lock and unlock the door from the inside without using the key.

Finish

- The powder coating process applied to the door and chassis is environmentally friendly. Minor scratches or marks are not covered under the conditions of our

warranty. Corrosives such as acids, alkalines, and salts, etc. should be cleaned from the door immediately; failure to do so will result in deterioration of the paint finish, which will not be covered under our warranty. (See warranty booklet for further details). If you choose to paint the door and frame first wash with a mild soapy solution and allow to dry, then prepare the surface with a single pack adhesion primer, ensuring you follow the manufacturers instructions then apply an eggshell or matt, oil based paint (cellulose paints must not be used). For timber panels see additional treatment instructions on the back of the door panel. For GRP panels no other finish is required.

Maintenance

If in doubt about any of these maintenance procedures below always consult a Hörmann specialist.

- Immediately after the door is fitted and after every 5,000 operations of the door, or at least once a year, oil all pivot points, check screws and clamped connections for tightness, keep the running tracks clean (do not grease them), check parts and replace any worn components where necessary.
- The springs should be replaced after approx. 25,000 operations by an experienced door fitter.
- Do not oil the lock cylinder; if it is sticking, only lubricate with graphite dust.

- For canopy doors only, check the cable every 6 months with normal usage (8 operations per day). Have the cables replaced by an expert if any wear is found.
- **Cleaning** - the door, and frame if applicable, should be washed with a mild soap-based solution on a regular basis (at least once every 6 months, or once a month in coastal areas) to prevent the build up of dirt, salts and other corrosive substances and help maintain the aesthetic appearance of the product. We also suggest that all other components be brushed down on a regular basis to prevent the build up of dirt and dust, etc.

Liability

Hörmann accept no responsibility for alterations made to this door, including changes which may affect the weight of the door.

Issue 10.03

Hörmann (UK) Ltd.
Gee Road, Coalville
Leicestershire. LE67 4JW

